






<p><b>1</b></p> 	<p><b>2</b></p> 
<p><b>3</b></p>  <p>A or B: depending on IT data facility (A and B refers to ANSI/TIA-568)</p>	<p><b>4</b></p> 
	<p>* If it is necessary to remove the cable from the terminal, please insert a suitable tool into the gap and pull the cable as shown in the image.</p> <p>If there is any question regarding the connection or suitability, please consult with Zennio Technical Support <a href="https://support.zennio.com">https://support.zennio.com</a>.</p>